# Lab7 Latent heat of Fusion of Ice Physics 132 Lab

Dominic Martinez-Ta

 $22~\mathrm{May}~2015$ 

# 0.1 Purpose

This experiment makes use of measuring the heat capacity of a calorimeter in order to improve the accuracy of a measurement of the latent heat of fusion of ice. In such a mueasurement, the heat transfers between ice, water, the calorimeter and the environment are given by:

$$Q_{water}(T_i \to T_f) = m_{water} \int_{T_i}^{T_f} c_p(T) dT$$
 (1)

$$Q_{cal}(T_i \to T_f) = \int_{T_i}^{T_f} C_{cal}(T) dT$$
 (2)

$$Q_{env}(T_i \to T_f) = \frac{Q_{cal}(T_i \to T_f)}{T_f - T_i} \frac{dT}{dt} \Delta t$$
 (3)

$$Q_{ice}(T_f) = m_{ice}L + m_{ice} \int_{0^{\circ}C}^{T_f} c_p(T)dT$$
(4)

And by conservation of energy:

$$\Delta U(T_i \to T_f) = Q_{water}(T_i \to T_f) + Q_{cal}(T_i \to T_f) + Q_{ice}(T_i \to T_f) = 0 \quad (5)$$

## 0.2 Materials and resources

- Calorimeter
- Digital scale
- Hot & cold water
- ice
- two 250 ML beakers
- Temperature sensor
- Data Studios
- Love

### 0.3 Procedure

#### Part I: Heat Capacity and the Calorimeter

The heat energy used to changef the temperature of the inner wall of the thermos is charactized by

$$mc_p(T_2 - T_f = C_{cal}(T_f - T_1)$$

- 1. Add 250 mL of cold water into the calorimeter. Allow several minutes for it to reach equilibirum.
- 2. Measure the common temperature of teh water and the calorimeter. (This will be  $T_1$ ).
- 3. pour out the water and measure the weight of the empty beaker.
- 4. Get 200 mL of hot water in the beaker.
- 5. Measure the temperature of the hot water in the beaker. Take 30 temperature readings in 30 seconds, and record the 30th reading as  $T_2$
- 6. Repeat this measurement two more times.
- 7. From the average of the three trials, calculate the uncertainty in L, only once, given by:

$$\Delta C_{cal} = C_{cal} \sqrt{\left(\frac{\Delta m_{water}}{m_{water}}\right)^2 + \left(\frac{\Delta T_{cal}}{T_{cal}}\right)^2}$$

#### Part II: Latent Heat of Fusion of Ice

- 1. Weigh the calorimeter plus the hot water together.
- 2. Record the initial temperature of the water and calorimeter,  $T_1$ . While gently stirring the water, record the temperature at 1 second intervals for 6 minutes, take measurements for about 1 minute and then proceed onto step number three. (Continue to take data and generate a graph of temperature vs. time.)
- 3. Carefully dry the ice cube in the Calorimeter. (HOW IS THAT POSSIBLE?!!)

- 4. The observed T vs. t graph should contain three distinct regimes: the initial constant temperature, a drastic drop in temperature, and the final temperature. Record a copy of T vs. t in the lab report
- 5. The temperature after the initial exchange of heat is the final temperature of the water, melted ice, and the calorimeter,  $T_f$
- 6. Weigh the calorimeter with the water and melted ice. Calculate the mass of the ice from this measure-ment and the previous measurement of the calorimeter and original water alone.
- 7. Repeat this measurement two more times, and take the average of the three trials for lab report calculations.
- 8. From the average of the three trials, calculate the uncertainty in L, only once, given by:

$$\Delta L = L\sqrt{[\delta(T_f - 271.15K)]^2 + [\delta(\Delta T)]^2 + [\frac{\Delta C_{cal}}{C_{cal}}]^2}$$

- 0.4 Data Analysis
- 0.5 Questions
- 0.6 Answers to questions
- 0.7 Conclusion
- 0.8 Data

Part I, chromium

$T_H(C)$	$T_C(C)$	$T_F(C)$	$M_{Total}(g)$	$m_{H_2O}(g)$	$m_{cup}(g)$	$m_{chromium}(g)$
77.0	63.7	59.7	145.73	136.22	2.00	7.51
65.7	49.9	47.6	125.88	115.37	_	_
52.5	33.8	31.6	125.76	116.25	_	_
34.6	18.6	18.2	126.42	116.91	_	_
21.4	4.2	3.1	122.34	112.83	_	_

## $\mathbf{Part}\ \mathbf{I},\,\mathrm{Copper}$

$T_H(C)$	$T_C(C)$	$T_F(C)$	$M_{Total}(g)$	$m_{H_2O}(g)$	$m_{cup}(g)$	$m_{Cu}(g)$
77.0	60.0	61.2	142.00	100.00	2.00	40.00
65.7	50.0	52.1	148.00	106.00	_	_
48.6	34.7	34.7	153.30	113.30	_	_
35.0	21.0	21.0	134.43	92.43	_	_
21.0	5.0	7.3	95.7	53.7	_	_

## ${\bf Part\ II},\,{\rm Chromium}$

$T_H(C)$	$T_C(C)$	$T_F(C)$	$M_{Total}(g)$	$m_{eth}(g)$	$m_{cup}(g)$	$m_{chromium}(g)$	$\frac{\partial m}{\partial t}$	$\Delta t(s)$
5.0	-10.0	-7.3	40.2	10.0	2.0	7.51	0.02	7
-10.11	-25	-24.41	38.5	_	_	_	0.01	8
-24.12	-40.0	-41.05	40.5	_	_	_	0.03	3
-40.00	-55.0	-54.45	44.6	_	_	_	0.02	5
-55.7	-75.0	-74.45	38.2	_	_	_	0.08	13

# Part II, Copper

$T_H(C)$	$T_C(C)$	$T_F(C)$	$M_{Total}(g)$	$m_{eth}(g)$	$m_{cup}(g)$	$m_{Cu}(g)$	$\frac{\partial m}{\partial t}$	$\Delta t(s)$
5.0	-9.8	-7.3	40.2	10.0	2.0	40.0	0.13	10
-10.2	-25.4	-24.41	38.5	_	_	_	0.15	9
-22.5	-39.9	-41.05	40.5	_	_	_	0.09	9
-42.3	-56.2	-54.45	44.6	_	_	_	0.15	11
-55.2	-75.5	-74.48	38.2	_	_	_	0.07	13